

Measuring amplifier GSV-1A4 SubD37/2/250Hz

Item number: 3601



Highlights

- Input sensitivity: 2 mV/V
- 4 mV/V, 2 mV/V, 1 mV/V, 0.5mV/V configurable via jumpers
- Output signals 10 V AND 12 mA+8 mA on 15 pin Sub-D
- Integrated half and quarter bridge completion for 350 ohm strain gauge
- Tare function individually via control cables and together via control cables and switches

The measuring amplifier GSV-1A4 is a measuring amplifier with 4 independent channels for sensors with strain gauges such as force sensors, torque sensors, acceleration sensors or extension sensors.

This measuring amplifier is also suitable for connecting strain gauge full and half bridges from 87.5 ohm to 5000 ohm and strain gauge quarter bridges with 350 ohm.

The measuring amplifier GSV-1A4 is supplied with a plug-in 18 V power supply and SUB-D mating plugs.

The voltage and current outputs are at the 15-pin Sub-D socket and one ground for each analogue output. Both outputs have been calibrated and can be used at the same time.

The voltage output is ± 10 V, the current output is 4...20 mA with zero adjustment to 12 mA (12mA+8mA).

The sensor inputs, bridge completions and the inputs for automatic zero adjustment of the individual channels are at the 37-pin Sub-D socket.

The bridge completion resistance with 0.1% tolerance for 350 ohm strain gauge is maintained. The quarter or half bridge mode can be set by the customer at the 37-pin Sub-D socket (see wiring diagram for 37-pin Sub-D socket).

As an option, it is possible to use the 6-wire technology of GSV-1L. The use of 6-wire technology must be configured to the circuit board.


GSV-1A4 M12 socket variant

The GSV-1A4 is optionally equipped with round connectors for the sensor connection.

The mating plugs must be ordered separately or are a component of the sensor.



Technical Drawing



Technical Data

Basic Data		Unit
Dimensions	106 x 173 x 32	mm ³
Housing	Aluminium	
Connection	Plug connector	
Connection type	SubD37/2	
Number of channels	4-channel	
Schnittstelle	±10V, 4...20mA	

Input analog		Unit
Input sensitivity-steps	0.5 1.0 2.0	mV/V
Strain-gauge-full-bridge resistance from	87	Ohm
Strain-gauge-full-bridge resistance to	5000	Ohm

Output analog		Unit
Voltage output from	-10	V
Voltage output to	10	V
Output resistance - voltage output	35	Ohm
Current output from	4	mA
Current output to	20	mA
Maximum load resistance - current output	35	Ohm

Accuracy data		Unit
---------------	--	------

Measuring frequency		Unit
Limit frequency (analog)	250	Hz

Supply		Unit
Supply voltage from	11	V
Supply voltage to	30	V
Strain gauge bridge supply	5	V

Interface	Unit
Type of the interface	Analog

Zero Adjustment		Unit
Type	Button	
Tolerance	5	mV
Time period	90	ms
Debouncing time	4	ms
Trigger level from	3.5	V
Trigger level to	30	V
Trigger edge	falling	

Environmental Data	Unit
--------------------	------

Mounting

Description	Channel 1 Color/PIN	Channel 2 Color/PIN	Channel 3 Color/PIN	Channel 4 Color/PIN
Output voltage	brown 2	yellow 5	red-white 15	light green 12

Output current	red 3	dark green 6	brown-white 14	pink 11
Ground	orange 4	blue 7	black-white 13	white 10

Automatic Zero-adjustment is operated via push button or via digital input. Advice: the GNDio PIN 1 for digital input with PIN 8 is isolated from analog Ground PIN4.

Analog grounds PIN4, PIN7, PIN13, PIN10 are connected.

Connect GNDio (PIN1) permanently with Ground (PIN4) and connect Supply Voltage (PIN9) via Relais or button with PIN8 for remote-controlled zero adjustment.

GNDio for digital input	black 1
Zero-adjustment input	purple 8
Supply Voltage output	grey 9

The colors correspond to the core colors of the supplied 3 m cable with 15-pin connector SubD15.

Symbol	Description	Channel 1	Channel 2	Channel 3	Channel 4
--------	-------------	-----------	-----------	-----------	-----------

+US	positive sensor power supply	20	2	11	29
+UF	positive sensor input	21	3	12	30
+UD	positive differential input	22	4	13	31
QB350	quarter bridge completion 350Ω *	23	5	14	32
HB	half bridge completion **	24	6	15	33
-UD	negative differential input **	25	7	16	34
-UF	negative sensor input	26	8	17	35
-US	negative sensor power supply	27	9	18	36
Tara	automatic zero-point adjustment	28	10	19	37
GND			Grund/Schirm 1		

* Half bridge completion must be activated at the same time.

** The negative differential input (25, 7,16, 34) must be connected to the corresponding half bridge completion (24, 6,15, 33).

Wiring diagram of a full bridge to SubD-37, channel 1-4

Wiring diagram of a half bridge to SubD-37, channel 1-4

Wiring diagram of a quarter bridge to SubD-37, channel 1-4

Adjusting the sensitivity

The sensitivity of channels 1 to 4 can be adjusted. On the circuit board of the GSV-1A4, each channel has a jumper post field with 4 plug options in total.

Opening the device

1.

All 4 screw covers and the fastening screws on each end cover should be removed.

2.

The cover with the (37-pin Sub-D socket) must be loosened using the two hexagonal bolts.

3.

The circuit board is unplugged from the side of the 15-pin Sub-D socket.

4.

In the M12 socket version, the cover is pushed through the housing slightly slanted.